

PAR Drive-Thru Headset G5

Quick Start Guide



Buttons

Volume Adjust Volume Level

Lane 2

Answer Lane 2 Order Point in Dual Lane

Paging

Talk to Other Headsets

Lane 1

Answer Lane 1 Order Point in Dual Lane

- Feather-touch buttons sense finger pad for a touch versus push
- Vibration confirms that the button has been pressed

NOTE: In a Single Lane operation, use Lane 1 or Lane 2 touch zones to answer the Order Point.

Light on Microphone Boom



- Green (Steady) Light: Lane 1 no car present, stand by
- Red/Green (Steady) Light: Lane 2 (Dual Lane) no car present, stand by
- Blue (Flashing) Light: Vehicle arrived, but not answered
- Blue (Steady) Light: Vehicle present and answered
- Red (Steady) Light: Talk (either lane or page)

Headset Charging Station and Batteries

Headset Charging Station Charge headsets without removing batteries

Battery

Four lights indicate 100% fully charged

Battery Removal



1. Place pointer finger between Control Pod and battery; place thumb under the battery latch.



2. Using a pinching motion, pinch and gently pull battery straight out.

Contact your 3M Representative Today

1-800-328-0033 3M.com/G5